

Keypad Comparison Chart

				
Basic Keypad	Basic Display Keypad	Advanced Keypad	Advanced Comfort Keypad	Advanced Paddle Keypad
FRM002	FRM072	FRM001	FRM066	FRM055
				
15 year warranty	15 year warranty	15 year warranty	15 year warranty	15 year warranty
X No one-touch height adjustment	X No one-touch height adjustment	✓ One-touch height adjustment	✓ One-touch height adjustment	✓ One-touch height adjustment
X Not able to choose one-touch or constant-touch modes	X Not able to choose one-touch or constant-touch modes	✓ Able to choose one-touch or constant-touch modes	✓ Able to choose one-touch or constant-touch modes	✓ Able to choose one-touch or constant-touch modes
X No memorized seated and standing height settings	X No memorized seated and standing height settings	✓ Memorized seated and standing height settings	✓ Memorized seated and standing height settings	✓ Memorized seated and standing height settings
X No child safety lock	X No child safety lock	✓ Child safety lock	✓ Child safety lock	✓ Child safety lock
X No min and max height settings	X No min and max height settings	✓ Min and max height settings	✓ Min and max height settings	✓ Min and max height settings
X No auto-dark display	✓ Auto-dark display	✓ Auto-dark display	✓ Auto-dark display	✓ Auto-dark display
X No desk height calibration	X No desk height calibration	✓ Desk height calibration	✓ Desk height calibration	✓ Desk height calibration
X No digital height display	✓ Digital height display	✓ Digital height display	✓ Digital height display	✓ Digital height display
X No collision sensitivity adjustments	✓ Collision sensitivity adjustments	✓ Collision sensitivity adjustments	✓ Collision sensitivity adjustments	✓ Collision sensitivity adjustments
X No soft-touch face	X No soft-touch face	X No soft-touch face	✓ Soft-touch face	X No soft-touch face
X No look controls	X No look controls	X No look controls	✓ No look controls	✓ No look controls
X Can't tap or double tap paddle up or down	X Can't tap or double tap paddle up or down	X Can't tap or double tap paddle up or down	X Can't tap or double tap paddle up or down	✓ Tap or double tap paddle up or down
X No standing reminders	X No standing reminders	X No standing reminders	X No standing reminders	✓ Standing reminders
X No graphical LED display	X No graphical LED display	X No graphical LED display	X No graphical LED display	✓ Graphical LED display
Angled profile when mounted to desktop	Angled profile when mounted to desktop	Flush with edge when mounted to desktop	Angled profile when mounted to desktop	Angled profile when mounted to desktop
				