

FRM053



Diagram illustrating the location of the Power indicator LED on the board. The LED is located near the power connector, as indicated by the callout.

[illegible]

Number of Legs	Control box program number	Bluetooth Adapter (FRM025)	Bluetooth Adapter (FRM125 or FRM225)	Advanced Paddle Keypad (FRM055)	Advanced Keypads Memory settings	Advanced Keypads Keypad lock	Advanced Keypads One-touch or constant touch	Advanced Keypads Display units (in or cm)	Advanced Keypads Height calibration	Advanced Keypads Min & max height settings	Advanced Keypads Anti-collision sensitivity
2-Leg	99.183.72.0046	No	No	✓	✓	✓	✓	✓	✓	✓	✓
2-Leg	99.183.72.3007	No	No	✓	✓	✓	✓	✓	✓	✓	✓
2-Leg	99.183.72.3008	No	No	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.110.32.0005	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.110.32.0055	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.046.14.0070	No	No	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.075.14.0038	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.075.14.0063	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.075.14.0064	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.190.47.3012	No	No	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.190.47.3013	No	✓	✓	✓	✓	✓	✓	✓	✓	✓
3-Leg	99.190.47.3170	No	✓	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.119.42.0031	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.119.42.0032	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.046.14.0071	No	No	No	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.052.09.0019	No	No	No	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.052.09.0030	No	No	No	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.052.05.0002	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.078.05.0002	No	No	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.078.05.0019	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.078.05.0031	No	No	✓	✓	✓	✓	✓	✓	✓	✓
4-Leg	99.078.05.0032	No	No	✓	✓	✓	✓	✓	✓	✓	✓

Copyright Notice: This guide is a component of this UPLIFT Desk product. This guide is a part of the scope of delivery, even if the item is resold.
This guide is also available on the UPLIFT Desk website: upliftdesk.com. These specifications are subject to United States copyright law.